



Key In



Amplifier Keying

Audio from Computer (Headphones)



Enable/Disable Pushbutton

Relay Keying

Audio to Speakers or Headphones



DC Power Socket

Tuner Socket

ACL Jack

SEND Jack



Antenna Connector

Accessory Socket

External Speaker Jack